



# **FCR-7** series

Return filters, tank top mounting, inside-to-outside filtration

# **Technical Information**

Pressure:	Max working Burst	8 bar (116 psi) (acc. to NFPA T 3.10.5.1) 16 bar (232 psi) (acc. to NFPA T 3.10.5.1)			
Connectio	on Ports: 1/2"÷2	2″ BSP (ot	her thread options on request)		
Materials: Head and top cover: Top cover (sizes 10 to 14 only): Insert holder: Diffuser: Seal:		over: ) to 14 only):	aluminium alloy nylon aluminium alloy zinc plated steel Buna-N (FKM on request)		
By-pass: 1	,7 bar (24.6 psi	)			
Filter Med	l <b>ia</b> : Microgla	ss fiber	4,5 - 7 - 12 - 27 μm(c) (acc. to ISO 16889)		
	Cellulose	2	10 - 25 μm(c) (acc. to ISO 16889)		
	Wire mes	sh	60 µm		
Differential burst pressure: 10 bar (145 psi) (acc. to ISO 2941)					
Filtrec elen	nents are tested a	also acco	rding to ISO 2942, ISO 23181 and ISO 3968		
Working t	emperature: -2	5°C +12	0°C (-13°F +248°F)		
<b>Fluid compatibility</b> (acc. to ISO 2943): Full with HH-HL-HM-HV (acc. to ISO 6743/4). For use with other fluid applications please contact Filtrec Customer Service (info@filtrec.it).					
	Pressure: Connectio Materials: By-pass: 1 Filter Med Differentio Filtrec elem Working t Fluid com Full with H For use wit	Pressure: Max working Burst Connection Ports: 1/2"÷2 Materials: Head and top of Top cover (sizes 10 Insert holder: Diffuser: Seal: By-pass: 1,7 bar (24.6 psi) Filter Media: Microglas Cellulose Wire mess Differential burst pressure Filtrec elements are tested of Working temperature: -2 Fluid compatibility (acc. to Full with HH-HL-HM-HV (acc	Pressure: Max working 8 bar (1) Burst 16 bar (2) Connection Ports: 1/2"÷2" BSP (of Materials: Head and top cover: Top cover (sizes 10 to 14 only): Insert holder: Diffuser: Seal: By-pass: 1,7 bar (24.6 psi) Filter Media: Microglass fiber Cellulose Wire mesh Differential burst pressure: 10 ba Filtrec elements are tested also acco Working temperature: -25°C +12 Fluid compatibility (acc. to ISO 29- Full with HH-HL-HM-HV (acc. to ISO 29- Full with HH-HL-HM-HV (acc. to ISO 29- Full with HH-HL-HM-HV (acc. to ISO 29- For use with other fluid applications		

FCR-7 series



Bh	HYNESUR
	And all the standards a support of the state of the



**R10** 

**Preferential option** 

pressure gauge 0÷4 bar / 0÷58 psi



# FCR-7 11 / 12 / 13 / 14





#### option "S" with diffusor option "O" without diffusor

# FCR-7 20 / 21 / 22



option "S" with diffusor / option "0" without diffusor

D1= 134 for option "S" / 131 for option "0"



# FCR-7 30 / 31 / 32 / 33



option "S" with diffusor / option "0" without diffusor



MULTIFIX FLANGE ALLOWING TWO TANK MOUNTING PATTERNS



D1= 166 for option "S" / 161 for option "0"

CODE	Α	H1	H2	R	WEIGHT
FCR-7-11	1/2" BSP	133	195	206	2 Kg
FCR-7-12	3/4" BSP	178	195	250	2,2 Kg
FCR-7-13	1″ BSP 1″ 1/4 BSP	228	345	300	2,4 Kg
FCR-7-14		328	345	400	2,8 Kg
FCR-7-20	1" BSP	233	310	330	5,3 Kg
FCR-7-21	1″ 1/4 BSP	303	310	400	5,6 Kg
FCR-7-22	1″ 1/2 BSP	508	515	610	6,9 Kg
FCR-7-30		265	360	380	7,2 Kg
FCR-7-31	1″ 1/2 BSP	345	360	460	7,5 Kg
FCR-7-32	2″ BSP	535	550	650	9,1 Kg
FCR-7-33		445	550	560	9,8 Kg

# Nominal size

For different thread options please contact Filtrec Customer Service.



# Pressure drop diagrams

The total Pressure Drop ( $\Delta p$ ) value is obtained by adding the  $\Delta p$  values of filter housing and filter element at the given flow rate. This ideally should not exceed 0,5 bar (7,3 psi) and should never exceed 1/3 of the set value of the by-pass valve.

#### PRESSURE DROP THROUGH THE FILTER HOUSING

The Pressure Drop through the filter housing is governed by the port, not the bowl length and the oil viscosity.

#### PRESSURE DROP THROUGH THE CLEAN FILTER ELEMENT

The Pressure Drop through the filter element is related both to the internal diameter of the filter element and to the filter media; this value is affected by the oil viscosity in a roughly proportional way: e.g. when the Dp value from the curve is 0,2 bar and a 46 cSt oil is used, the corresponding value is 0,31 (=0,2 x 46/30) bar.



#### Element R-7-13



#### Housing FCR-7- 11/12/13/14



Element R-7-12



Element R-7-14





#### PRESSURE DROP THROUGH THE FILTER HOUSING

The Pressure Drop through the filter housing is governed by the port, not the bowl length and the oil viscosity.

#### PRESSURE DROP THROUGH THE CLEAN FILTER ELEMENT

The Pressure Drop through the filter element is related both to the internal diameter of the filter element and to the filter media; this value is affected by the oil viscosity in a roughly proportional way: e.g. when the Dp value from the curve is 0,2 bar and a 46 cSt oil is used, the corresponding value is 0,31 (=0,2 x 46/30) bar.





Housing FCR-7- 20/21/22



Element R-7-21





#### PRESSURE DROP THROUGH THE FILTER HOUSING

The Pressure Drop through the filter housing is governed by the port, not the bowl length and the oil viscosity.

#### PRESSURE DROP THROUGH THE CLEAN FILTER ELEMENT

The Pressure Drop through the filter element is related both to the internal diameter of the filter element and to the filter media; this value is affected by the oil viscosity in a roughly proportional way: e.g. when the Dp value from the curve is 0,2 bar and a 46 cSt oil is used, the corresponding value is 0,31 (=0,2 x 46/30) bar.







Housing FCR-7- 30/31/32/33



Element R-7-31



Element R-7-33







The above diagrams have been obtained at the FILTREC laboratory, according to the ISO 3968 specification, with mineral oil having 30 cSt viscosity and 0,86 Kg/dm3 density.

In case of discrepancy, please check contamination level, viscosity and features of the oil in use and the sampling points of the differential pressure.



# **Clogging indicator**

The Pressure Drop ( $\Delta p$ ) through the filter increases during the system operation due to the contaminant retained by the filter element.

The filter element must be replaced when the indicator shows and before the  $\Delta p$  reaches the by-pass value setting. N.B. in cold start conditions a false alarm can be caused by higher oil viscosity due to low temperature; the indicator alarm must be considered at normal working temperature only.

The clogging indicator registers the pressure upstream the filter element:

- •in the VISUAL indicator the red area shows the need for element replacement.
- in the ELECTRIC indicator an electrical switch is activated.

#### **PRESSURE SWITCH**



#### VISUAL PRESSURE GAUGE



STMBOL	CODE	SETTING
	R6	1,3 bar (18,9 psi)
•L		

#### PRESSURE/ VACUUM GAUGE



SYMBOL	CODE	SCALE
$\bigcirc$	D7	0 ÷1,4 bar (0 ÷20 psi) green sector
	κ/	1,4÷5 bar (20 ÷72,5 psi) red sector
i		

N.B. Multipurpose product: this gauge can also be used as vacuum gauge on suction filters.

PRESSURE GAUGE





SYMBOL	CODE	SCALE	
	R9	0 ÷1 bar (0 ÷14,5 psi) green sector	
$ $ $\psi$ $ $		1 ÷1,5 bar (14,5 ÷22 psi) yellow sector	
		1,5÷4 bar (22 ÷58 psi) red sector	

Housing in black ABS material

Housing in black ABS material

SYMBOL	CODE	SCALE
$(\uparrow)$	R10	0 ÷1 bar (0 ÷14,5 psi) green sector
$\Psi$		1 ÷1,5 bar (14,5 ÷22 psi) yellow secto
		1,5÷4 bar (22 ÷58 psi) red sector

Housing in black ABS material

**Preferential option** 

# **User Tips**





BOLTS / COVER TIGHTENING TORQUE			
FCR-7- 11/12/13/14	15 Nm		
FCR-7- 20/21/22	5 Nm		
FCR-7- 30/31/32/33	5 Nm		

### Installation

Make sure that the filter flange is well secured on the tank lid through the fixing holes and that the hose is properly connected to the IN port.

After mounting verify that no tension is present on the filter.

Make sure that enough space is available for filter element replacement and that the clogging indicator is in a easily viewable position. If an electrical indicator is used, make sure that it is properly wired.

We recommend the stocking of a spare FILTREC filter element for timely replacement when required.

# Operation

Make sure that the filter works within the conditions of pressure, temperature and fluid compatibility given in the first page of this data sheet. The filter element must be replaced as soon as the clogging indicator signals at working temperature (in cold start conditions, oil temperature lower than 30°C, a false alarm can be given due to oil viscosity). If no clogging indicator is mounted, make sure that the cartridge is replaced according to the system manufacturer's recommendations.

### Maintenance

Before removing the top cover, ensure that the system is switched off and there is no residual pressure in the filter.

Remove the top cover by unscrewing the fixing bolts. Remove the spring first and extract the insert assembly (warning : a certain quantity of oil can be retained within the filter element, provide to have a proper container available for it); unscrew the nut at the bottom of the insert and slip the dirty filter element carefully. Clean the tie rod (and the magnets if present) and check the support gaskets conditions, replace them if necessary. Fit a new FILTREC element (verify first the part number, particularly concerning the micron rating; open the plastic protection of the element from the the top and fit the element over the tie rod, then remove completely the plastic protection) and block it by tightening the bottom nut. Put the insert assembly into the head, put the spring in its position over the insert support, then mount the top cover and tighten properly the fixing bolts.

N.B. The used filter elements cannot be cleaned and re-used.

### **PED Compliance**

FCR-7 filters conform to PED 97/23/CE norm, article 3 section 3, and so they can be used with fluids of group 2 (liquids with steam pressure < 0.5 bar at the maximum allowable temperature, article 3, section 1.1(b) – sub-section II).

#### WARNING

Make sure that Personal Protective Equipment (PPE) is worn during installation and maintenance operation.

### **Disposal of filter elements**

The used filter elements and the filter parts dirty of oil are classified as "Dangerous waste material": they must be disposed according to the local laws by authorized Companies.





# SUMINISTROS DE HIDRÁULICA Y NEUMÁTICA DEL SUR, S.L.

Pol. Ind. Los Palillos, Calle 6 Nave 31 41500 Alcalá de Guadaira SEVILLA Tel. 954 047 523 Fax. 955 631 705 hynesur@hynesur.com





www.filtrec.com



Technical information may change without notice